

## Momentum Preamplifier 12V trigger addendum

For use with the Momentum Preamplifier and multiple Momentum amplifiers

Place the Momentum preamplifier in standby using the front panel button.

1. Turn off both Momentum amplifiers with the button on the bottom front of the amplifier
2. Unplug the Momentum amplifiers from the AC outlet.
3. Connect the 12V trigger output from the Momentum preamplifier to the input of the first Momentum amplifier
4. Connect the 12v trigger output of the first Momentum amplifier to the input of the second Momentum amplifier
5. Plug both Momentum amplifiers to the AC outlet
6. Turn on the preamplifier from standby to operate.
7. The Momentum amplifiers should now turn on as well.